



2026 Audi Service

1 Maintenance Schedules

⇒ Maintenance Schedule (Gas and Hybrid Vehicles)

⇒ Maintenance Schedule (Battery Electric Vehicles)

1.1 Maintenance Schedule (Gas and Hybrid Vehicles)

Note

The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes and the cleaning or replacing of the air cleaner filter element.

Service Intervals								
— Miles	10K	20K	30K	40K	50K	60K	70K	80K
— Kilometers	15K	30K	45K	60K	75K	90K	105K	120K
⇒ Minor Maintenance ¹⁾	X		X		X		X	
⇒ Standard Maintenance ²⁾		X		X		X		X
⇒ Additional Maintenance Items								
¹⁾ First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first.								
²⁾ First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.								

✓ all completed items

1.1.1 Minor Maintenance

Service Item	Applicability
☐ Brake system - Check the thickness of the brake pads	All Vehicles
☐ Engine oil & oil filter - Change oil and replace filter	All Vehicles
☐ Multi-point inspection - Complete (USA Only)	All Vehicles
☐ Service reminder indicator display - Reset display	All Vehicles
☐ Tire repair kit - Check and record the completeness and expiration date (if equipped)	All Vehicles
☐ See ⇒ Additional Maintenance Items	All Vehicles



1.1.2 Standard Maintenance

Service Item	Applicability
☐ Body / chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open	All Vehicles
☐ Brake system - Check for damage and leaks, condition of brake hoses and the presence of the bleeder caps; Check the thickness of the brake pads	All Vehicles
☐ Connected box / OCU / ConMod battery (for Audi Connected Services) - Check state health with Vehicle Diagnostic Tester in Guided Functions	All Vehicles
☐ CTG Label - Check for CTG (Certification Test Group) label is present, undamaged, and legible in the engine compartment. Use the Vehicle Diagnostic Tester to verify the certification test group engine family number on the label matches the engine control module	All Vehicles
☐ Door hinges (including door stay) and door latch - Lubricate	All Vehicles
☐ Engine cooling system - Check freeze protection and coolant level	All Vehicles
☐ Engine oil & oil filter - Change oil and replace filter	All Vehicles
☐ Engine, transmission, final drive, steering (with front noise insulation removed) - Visual inspection for leaks and damage (including visible HV components of PHEV vehicles)	All Vehicles
☐ Exterior lighting function - Check front and rear lights (high beams, low beams, turn signals, cornering lights, brake lights, reverse lights, license plate lights, fog lights, and hazard warning lights)	All Vehicles
☐ First aid kit (if equipped) - Check and enter expiration date YYYY / MM _____	All Vehicles
☐ Headlights - Check adjustment	All Vehicles
☐ Horn - Check function	All Vehicles
☐ Instrument cluster - Check warning and indicator lights	All Vehicles
☐ Interior lights - Check all interior lights, trunk/cargo lights and glove box compartment illumination	All Vehicles
☐ Multi-point inspection - Complete (USA Only)	All Vehicles
☐ Plenum chamber and water drain valves - Check for dirt. and clean if necessary NOTE: Time spent cleaning of item is a separate charge for service time	A6 (all models) A7 (all models) A8 (all models) Q7 (all models) Q8 (all models) Q5 (GU) (all models)
☐ Road test - Perform	All Vehicles
☐ Safety belts- Check function and condition of belt, belt tongue, and latch	All Vehicles
☐ Service reminder indicator display - Reset display	All Vehicles
☐ Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)	All Vehicles
☐ Spare tire (if equipped) - Check condition of wheel, tire, tire inflation pressure; adjust if necessary	All Vehicles
☐ Sunroof systems - Check function (if equipped)	All Vehicles



Service Item	Applicability
☐ Suspension and axle components (front and rear) - Check dust seals on ball joints and tie rod ends; check for excessive play	All Vehicles
☐ Tires - Check condition and tire tread wear; Check and record the tread depth	All Vehicles
☐ Tires - Check tire inflation pressure and adjust if necessary	All Vehicles
☐ Tire repair kit - Check and record the completeness and expiration date (if equipped)	All Vehicles
☐ Torque splitter - Inspect for heat/performance exposure with Vehicle Diagnostic Tester according to ELSA (fluid change required when exceeding 25 kWh; refer also to Additional Maintenance)	RS3, S3
☐ Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are properly mounted (including visible HV components of PHEV vehicles)	All Vehicles
☐ Warning triangle and first aid kit (if equipped) - Check if present	All Vehicles
☐ Windshield washer and headlight washing system - Add fluid if necessary; Check adjustment and function	All Vehicles
☐ Wiper blades - Check condition and replace if necessary	All Vehicles
☐ See ⇒ Additional Maintenance Items	All Vehicles

1.1.3 Additional Maintenance Items

Service Item	Interval	Applicability
☐ Air filter - Replace	Every 60,000 miles (90K km)	All Vehicles except: RS 6 RS 7 Q5
	Every 40,000 miles (60K km)	SQ5
	Every 20,000 miles (30K km)	RS 6 RS 7
☐ AWD clutch - Change fluid (if equipped)	Every 3 years regardless of mileage	A3 Q3 (FJ)
☐ Brake and Clutch System, Changing Brake Fluid	Every 2 years regardless of mileage	All Vehicles
☐ Dust and pollen filter - Replace	Every 20,000 miles (30K km) or 2 years, whichever occurs first	All Vehicles
☐ Fragrance cartridges - Change (if equipped)	Every 2 years regardless of mileage	Only Vehicles with 2V9 PR-Code
☐ Front Differential - Change MTF	Only once at first 20,000 miles (30K km)	RS3
☐ Panorama sunroof systems (PSD) - Check drainage system by fluid check	Every 20,000 miles (30K km) or 2 years, whichever occurs first	All Vehicles with 3FU PR-Code
☐ Rear axle, quattro® sport - Change ATF and differential oil	Every 60,000 miles (90K km)	SQ7 SQ8, RS Q8



Service Item	Interval	Applicability
☐ Ribbed V-Belt	Every 140, 000 miles (230 km)	A5 Q5
☐ Ribbed V-belt starter / generator drive (including tensioner) - Replace	Every 60,000 miles (90K km)	
☐ Spark plugs - Replace	Every 30,000 miles (45K km) or 3 years, whichever occurs first	RS3 RS 6 RS 7 S8 SQ7 SQ8, RS Q8
	Every 40,000 miles (60K km) or 6 years, whichever occurs first	S3 A5 , S5 A6 (FN) A6 allroad A8 Q3 (FJ) Q5, SQ5 Q7 (2.0 L), Q7 (3.0 L) Q8
	Every 80,000 miles (120K km) or 6 years, whichever occurs first	A3 (2.0 L)
☐ S tronic transmission - Change fluid	Every 40,000 miles (60K km)	RS3 S5 A6 (FN), A6 allroad SQ5
	Every 60,000 miles (90K km)	A5 Q5
	Every 80,000 miles (120K km)	A3 S3 Q3 (FJ)
☐ Torque splitter (left / right) - Change ATF	Every 40,000 miles (60K km) or 4 years, whichever occurs first	S3 RS3

1.2 Maintenance Schedule (Battery Electric Vehicles)

Note

The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals.

Service Intervals									
– Miles	10K	20K	30K	40K	50K	60K	70K	80K	
– Kilometers	15K	30K	45K	60K	75K	90K	105 K	120 K	
⇒ Minor Maintenance ¹⁾	X		X		X		X		



Service Intervals

⇒ Standard Maintenance ²⁾		X		X		X		X
⇒ Additional Maintenance Items								
¹⁾ First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first. ²⁾ First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.								

✓ all completed items

1.2.1 Minor Maintenance

Service Item	Applicability
☐ Brake system - Check the thickness of the brake pads	All BEV
☐ Connected box / OCU battery (for Audi Connected Services) - Check state health with Vehicle Diagnostic Tester in Guided Functions	All BEV
☐ First aid kit - Check and enter expiration date YYYY / MM _____ (if applicable)	All BEV
☐ Front and rear axle / suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play	All BEV
☐ Instrument cluster - Check warning and indicator lights	All BEV
☐ Multi-point inspection - Complete (USA Only)	All BEV
☐ Service reminder indicator display - Reset display	All BEV
☐ Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)	All BEV
☐ Tires - Check condition and tire tread wear; Check and record the tread depth.	All BEV
☐ Tires - Check tire inflation pressure and adjust if necessary	All BEV
☐ Tire repair kit - Check and record the completeness and expiration date (if equipped)	All BEV
☐ Wiper blades - Check condition and replace if necessary	All BEV
☐ See ⇒ Additional Maintenance Items	All BEV

1.2.2 Standard Maintenance

Service Item	Applicability
☐ Air conditioner: check	Q4 e-tron equipped with heat pump PR Nr. 9M3
☐ Body / chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open	All BEV
☐ Brake system - Check for damage and leaks, condition of brake hoses and the presence of the bleeder caps; Check the thickness of the brake pads	All BEV
☐ Charging cable - Check for damage (if present in vehicle during inspection)	All BEV



Service Item	Applicability
☐ Charging socket - Check for contamination and damage	All BEV
☐ Connected box / OCU / ConMod battery (for Audi Connected Services) - Check state health with Vehicle Diagnostic Tester in Guided Functions	e-tron GT, RS e-tron GT Q4 e-tron, Q4 Sportback e-tron A6 e-tron Q6 e-tron
☐ Coolant expansion tank: check presence if sealing	A6 e-tron Q6 e-tron
☐ Electrical Components cooling system - Check coolant level according to ElsaPro procedure	A6 e-tron e-tron GT, RS e-tron GT Q4 e-tron, Q4 Sportback e-tron Q6 e-tron
☐ Door hinges (including door stay) and door latch - Lubricate	All BEV
☐ Exterior lighting function - Check front and rear lights (high beams, low beams, turn signals, cornering lights, brake lights, reverse lights, license plate lights, fog lights, and hazard warning lights)	All BEV
☐ First aid kit (if equipped) - Check and enter expiration date YYYY / MM _____	All BEV
☐ Headlights - Check adjustment	All BEV
☐ High voltage cooling system - Check coolant level according to ElsaPro	All BEV
☐ High voltage safety instruction labels - Check safety instruction labels for legibility	All BEV
☐ High voltage system components- - Check for damage and leaks; check cables and insulation for damage and proper mounting	All BEV
☐ High voltage system maintenance connector- - Check for damages (deformation and scratches) and connector cleanliness	All BEV
☐ Horn - Check function	All BEV
☐ Instrument cluster - Check warning and indicator lights	All BEV
☐ Interior lights - Check all interior lights, trunk/cargo lights and glove box compartment illumination	All BEV
☐ Motor compartment - Check transmission, final drive, and steering for leaks and damage (including visible HV components with front noise insulation removed)	All BEV
☐ Multi-point inspection - Complete (USA Only)	All BEV
☐ Parking brake actuator - Check activating range with Vehicle Diagnostic Tester	e-tron GT, RS e-tron GT
☐ Plenum chamber and water drain valves - Check for dirt. and clean if necessary NOTE: Time spent cleaning of item is a separate charge for service time.	A6 e-tron Q6 e-tron
☐ Road test - Perform	All BEV
☐ Safety belts- Check function and condition of belt, belt tongue, and latch	All BEV
☐ Service reminder indicator display - Reset display	All BEV
☐ Spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)	All BEV
☐ Sunroof and panoramic sunroof systems - Check function (if equipped)	All BEV



Service Item	Applicability
☐ Suspension and axle components (front and rear) - Check dust seals on ball joints and tie rod ends; check for excessive play	All BEV
☐ Tires - Check condition and tire tread wear; Check and record the tread depth.	All BEV
☐ Tires - Check tire inflation pressure and adjust if necessary	All BEV
☐ Tire repair kit (if equipped) - Check and record the completeness and expiration date	All BEV
☐ Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are properly mounted (including visible HV components)	All BEV
☐ Warning triangle and first aid kit (if equipped) - Check if present	All BEV
☐ Windshield washer and headlight washing system - Add fluid if necessary; Check adjustment and function	All BEV
☐ Wiper blades - Check condition and replace if necessary	All BEV
☐ See ⇒ Additional Maintenance Items	All BEV

1.2.3 Additional Maintenance Items

Service Item	Interval	Applicability
☐ Brake fluid - Change	Every 2 years regardless of mileage	All BEV
☐ Dust and pollen filter - Replace	Every 20,000 miles (30K km) or 2 years, whichever occurs first	All BEV
☐ Panorama sunroof systems (PSD) - Check drainage system by fluid check (only PR code 3FU)	Every 20,000 miles (30K km) or 2 years, whichever occurs first	A6 e-tron Q4 e-tron Q6 e-tron



© 12.2025 Audi of America, Inc.

All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Audi of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.