



2019 Audi Service

1 MY 2019 Maintenance Schedules

⇒ MY 2019 Maintenance Schedule (Gas and Hybrid Vehicles)

⇒ MY 2019 Maintenance Schedule (Electric Vehicles)

1.1 MY 2019 Maintenance Schedule (Gas and Hybrid Vehicles)

Note

The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes and the cleaning or replacing of the air cleaner filter element.

Service Intervals								
— Miles	10K	20K	30K	40K	50K	60K	70K	80K
— Kilometers	15K	30K	45K	60K	75K	90K	105K	120K
⇒ Minor Maintenance ¹⁾	X		X		X		X	
⇒ Standard Maintenance ²⁾		X		X		X		X
⇒ Additional Maintenance Items								
¹⁾ First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first.								
²⁾ First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.								

✓ all completed items

1.1.1 Minor Maintenance

Service Item	Applicability
☐ Brake system - Check the thickness of the brake pads	All Vehicles
☐ Engine oil & oil filter - Change oil and replace filter	All Vehicles
☐ Multi-point inspection - Complete (USA Only)	All Vehicles
☐ Service reminder indicator display - Reset display	All Vehicles
☐ Tire repair kit - Check and record the completeness and expiration date (if equipped)	All Vehicles
☐ See ⇒ Additional Maintenance Items	All Vehicles



1.1.2 Standard Maintenance

Service Item	Applicability
☐ Body/chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open	All Vehicles
☐ Brake system - Check for damage and leaks, condition of brake hoses and the presence of the bleeder caps; Check the thickness of the brake pads	All Vehicles
☐ Connected box battery (for Audi Connected Services) - Check state of health with Vehicle Diagnostic Tester in Guided Functions	- A4, S4, A4 all-road® - A5, S5, RS 5 - A6, A7, A8L - Q5, SQ5 - Q7, Q8
☐ Convertible top - Lubricate latch mechanism	A5 Cabriolet, S5 Cabriolet
☐ Door hinge (including door stay) and door latch - Lubricate	All Vehicles
☐ Engine cooling system - Check freeze protection and coolant level	All Vehicles
☐ Engine oil & oil filter - Change oil and replace filter	All Vehicles
☐ Engine, transmission, final drive, steering - Visual inspection for leaks and damage	All Vehicles
☐ Exterior lighting - Check front and rear lights, turn signals, cornering lights, reverse lights, license plate lights, and hazard warning lights	All Vehicles
☐ First aid kit - Check and enter expiration date YYYY / MM _____	All Vehicles
☐ Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play	All Vehicles
☐ Headlights - Check adjustment	All Vehicles
☐ Hood safety catch - Lubricate	A3, S3, RS 3
☐ Horn - Check function	All Vehicles
☐ Instrument cluster - Check warning and indicator lights	All Vehicles
☐ Interior lights - Check all interior lights, trunk lights and glove box compartment illumination	All Vehicles
☐ Multi-point inspection - Complete	All Vehicles
☐ Plenum chamber and water drain valves - Check for dirt. NOTE: Time spent cleaning of item is a separate charge for service time.	- A6 (all models) - A7 (all models) - A8L (all models) - Q7 (all models) - Q8 (all models)
☐ Road test - Perform	All Vehicles
☐ Rollover protection - Check the rollover protection when the convertible top is open	A3 Cabriolet
☐ Safety belts- Check function	All Vehicles
☐ Service reminder indicator display - Reset display	All Vehicles
☐ Spare tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)	All Vehicles



Service Item	Applicability
☐ Spoiler - Lubricate rear spoiler	TT, TT Roadster
☐ Sunroof systems - Check function (if equipped)	All Vehicles
☐ Tires - Check condition and tire tread wear; Check and record the tread depth.	All Vehicles
☐ Tires - Check tire inflation pressure and adjust if necessary	All Vehicles
☐ Tire repair kit - Check and record the completeness and expiration date (if equipped)	All Vehicles
☐ Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are properly mounted	All Vehicles
☐ Warning triangle - Check if present (if equipped)	All Vehicles
☐ Windshield washer and headlight washing system - Add fluid if necessary; Check adjustment and function	All Vehicles
☐ Wiper blades - Check condition and replace if necessary	All Vehicles
☐ See ⇒ Additional Maintenance Items	All Vehicles

1.1.3 Additional Maintenance Items

Service Item	Interval	Applicability
☐ Air filter - Replace	Every 60,000 miles (90K)	All Vehicles
☐ AWD clutch - Change fluid (if equipped)	Every 3 years regardless of mileage	- A3 45 TFSI, S3, RS 3 - Q3 45 TFSI - TT Coupe 45 TFSI, TT Roadster 45 TFSI - TTS, TT RS Coupe
☐ Brake and Clutch System, Changing Brake Fluid	Every 2 years regardless of mileage	All Vehicles
☐ Dust and pollen filter - Replace	Every 20,000 miles (30K) or 2 years, whichever occurs first	All Vehicles
☐ Fragrance cartridges - Change (if equipped)	Every 2 years regardless of mileage	All Vehicles with 2V9 PR-Code
☐ Panoramic sunroof systems (PSD) - Check drainage system by fluid check according to Elsa (if equipped)	Every 20,000 miles (30K) or 2 years, whichever occurs first	All Vehicles with 3FU PR-Code
☐ Rear axle, quattro® sport - Oil and ATF fluid changes	Every 60,000 miles (90K)	RS 5
☐ Ribbed V-belt compressor drive - Replace	Every 60,000 miles (90K)	Q7 55 TFSI
☐ Ribbed V-belt starter/generator drive (including tensioner) - Replace	Every 60,000 miles (90K)	A6 45 TFSI
☐ Spark plugs - Replace	Every 30,000 miles (45K) or 3 years, whichever occurs first	- RS 3 - TT RS Coupe - RS 5 - A8L 60 TFSI



Service Item	Interval	Applicability
☐ Spark plugs - Replace	Every 40,000 miles (60K) or 6 years, whichever occurs first	- S3 - TTS - A4 40 TFSI, A4 45 TFSI, S4 - A4 allroad® 45 TFSI - A5 45 TFSI, S5 - A6 45 TFSI, A6 55 TFSI, A7 55 TFSI - A8L 55 TFSI - Q5 45 TFSI, SQ5 - Q7 45 TFSI - Q8 55 TFSI
☐ Spark plugs - Replace	Every 60,000 miles (90K) or 6 years, whichever occurs first	Q7 55 TFSI
☐ Spark plugs - Replace	Every 80,000 miles (120K) or 6 years, whichever occurs first	- A3 40 TFSI, A3 45 TFSI - TT Coupe 45 TFSI, TT Roadster 45 TFSI - Q3 45 TFSI
☐ S tronic transmission - Change fluid	Every 40,000 miles (60K)	- RS 3 - A4 40 TFSI, A4 45 TFSI, - A4 allroad® 45 TFSI - A5 45 TFSI - A6 45 TFSI, A6 55 TFSI - A7 55 TFSI - Q5 45 TFSI - TT RS Coupe
☐ S tronic transmission - Change fluid	Every 80,000 miles (120K)	- A3 40 TFSI, A3 45 TFSI, S3 - TT Coupe 45 TFSI, TT Roadster 45 TFSI, TTS Coupe

1.2 MY 2019 Maintenance Schedule (Electric Vehicles)

Note

The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals.

Service Intervals								
— Miles	10K	20K	30K	40K	50K	60K	70K	80K
— Kilometers	15K	30K	45K	60K	75K	90K	105K	120K
⇒ Minor Maintenance ¹⁾	X		X		X		X	
⇒ Standard Maintenance ²⁾		X		X		X		X
⇒ Additional Maintenance Items								



Service Intervals

- 1) First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first.
- 2) First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.

✓ all completed items

1.2.1 Minor Maintenance

Labor Item	Applicability
☐ Brake system - Check the thickness of the brake pads	All Vehicles
☐ Connected box battery (for Audi Connected Services) - Check state health with Vehicle Diagnostic Tester in Guided Functions	All Vehicles
☐ First aid kit - Check and enter expiration date YYYY / MM _____ (if applicable)	All Vehicles
☐ Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play	All Vehicles
☐ Instrument cluster - Check warning and indicator lights	All Vehicles
☐ Multi-point inspection - Complete (USA Only)	All Vehicles
☐ Service reminder indicator display - Reset display	All Vehicles
☐ Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)	All Vehicles
☐ Tires - Check condition and tire tread wear; Check and record the tread depth.	All Vehicles
☐ Tires - Check tire inflation pressure and adjust if necessary	All Vehicles
☐ Tire repair kit - Check and record the completeness and expiration date (if equipped)	All Vehicles
☐ Wiper blades - Check condition and replace if necessary	All Vehicles
☐ See ⇒ Additional Maintenance Items	All Vehicles

1.2.2 Standard Maintenance

Service Item	Applicability
☐ Body/chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open	All Vehicles
☐ Brake system - Check the thickness of the brake pads	All Vehicles
☐ Brake system - Check for damage and leaks, condition of brake lines, and presence of bleeder caps	All Vehicles
☐ Charging socket - Check cable for damage	All Vehicles
☐ Charging socket - Check for contamination and damage	All Vehicles
☐ Connected box battery (for Audi Connected Services) - Check state of health with Vehicle Diagnostic Tester in Guided Functions	All Vehicles



Service Item	Applicability
☐ Cooling system for electrical components - Check coolant level and add if necessary according to procedure in ElsaPro Note: Perform after all other cooling system maintenance has already been performed.	All Vehicles
☐ Door hinges (including door stay) - Lubricate	All Vehicles
☐ Exterior lighting - Check front and rear lights, turn signals, cornering lights, reverse lights, brake lights, license plate lights, and hazard warning lights	All Vehicles
☐ First aid kit - Check and enter expiration date YYYY / MM _____ (if applicable)	All Vehicles
☐ Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play	All Vehicles
☐ Front axle drive - drain coolant (with small cover removed)	All Vehicles
☐ Headlights - Check adjustment	All Vehicles
☐ High voltage cooling system - Check for damage and leaks	All Vehicles
☐ High voltage safety instruction labels - Check safety instruction labels for legibility	All Vehicles
☐ High voltage system components- -Check for damage and leaks; check cables and insulation for damage and proper mounting	All Vehicles
☐ Horn - Check function	All Vehicles
☐ Instrument cluster - Check warning and indicator lights	All Vehicles
☐ Interior lights - Check all interior lights, trunk lights, and glove box compartment illumination	All Vehicles
☐ Motor compartment - Check transmission, final drive, and steering for leaks	All Vehicles
☐ Multi-point inspection - Complete	All Vehicles
☐ Plenum chamber and water drain valves - Check for dirt. and clean if necessary NOTE: Time spent cleaning of item is a separate charge for service time.	All Vehicles
☐ Road test - Perform	All Vehicles
☐ Safety belts- Check function	All Vehicles
☐ Service reminder indicator display - Reset display	All Vehicles
☐ Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)	All Vehicles
☐ Sunroof system - Check function (if equipped)	All Vehicles
☐ Tires - Check condition and tire tread wear; Check and record the tread depth.	All Vehicles
☐ Tires - Check tire inflation pressure and adjust if necessary	All Vehicles
☐ Tire repair kit - Check and record the completeness and expiration date (if equipped)	All Vehicles
☐ Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are properly mounted	All Vehicles
☐ Warning triangle and first aid kit - Check if present (if equipped)	All Vehicles
☐ Windshield washer and headlight washing system - Add fluid if necessary; Check adjustment and function	All Vehicles



Service Item	Applicability
☐ Wiper blades - Check condition and replace if necessary	All Vehicles
☐ See ⇒ Additional Maintenance Items	All Vehicles

1.2.3 Additional Maintenance Items

Service Item	Interval
☐ Brake fluid - Change	Every 2 years regardless of mileage
☐ Dust and pollen filter - Replace	Every 20,000 miles (30K) or 2 years, whichever occurs first
☐ Fragrance cartridges - Change (if equipped)	Every 2 years regardless of mileage
☐ Panoramic sunroof systems (PSD)- Check drainage system by fluid check according to Elsa (if equipped)	Every 20,000 miles (30K) or 2 years, whichever occurs first
☐ Rear axle drive - Replace coolant cartridge (with cover re- moved)	Every 20,000 miles (30K) or 2 years, whichever occurs first



© 04.2024 Audi of America, Inc.

All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Audi of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.