2009 VW Service

1 Maintenance Schedules

⇒USA Maintenance Schedule (Except Routan)

⇒Canada Maintenance Schedule (Except Routan)

⇒Maintenance Schedule (Routan Only)

1.1 USA Maintenance Schedule (Except Routan)

✓ all completed items

1.1.1 Service every 5,000 miles or 1 Year after Last Service

Labor Item
☐ AdBlue Fluid: Check and add fluid if necessary (3.0 L TDI only)

1.1.2 Service at 10,000 miles or 1 Year after Last Service

Labor Item
☐ Brake Pads: Check thickness
☐ Engine: Change oil and replace oil filter
☐ Headlamps: Check cleaning nozzle functionality (if applicable)
☐ Rear Window: Check cleaning nozzle functionality (if applicable)
☐ Service Interval Display: Reset
☐ Service label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐ Tires: Rotate front to rear
☐ Windshield: Check cleaning nozzle functionality
☐ Wiper Blades: Check functionality

1.1.3 Service at 20,000 miles or 1 Year after Last Service

Labor Item
☐ Battery: Check
☐ Brakes: Inspect brake system for leaks and damage, check thickness of brake pads and check brake fluid level
☐ Engine: Change oil and replace oil filter
☐ Fuel Filter: Replace (2.0L TDI only)
☐ Fuel Filter: Drain water (3.0 L TDI only)
☐ Headlamps: Check cleaning nozzle functionality (if applicable)
☐ Rear Window: Check cleaning nozzle functionality (if applicable)

Labor Item	
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality

1.1.4 Service at 30,000 miles or 1 Year after Last Service

Labor Item	
☐	Brake Pads: Check thickness
☐	Engine: Change oil and replace oil filter
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Tires: Rotate front to rear
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality

1.1.5 Service at 40,000 miles or 1 Year after Last Service

Labor Item	
☐	Battery: Check
☐	Body: Visual inspection for corrosion
☐	Brakes: Inspect brake system for leaks and damage, check thickness of brake pads, and check brake fluid level
☐	Coolant Level And Frost Protection: Check
☐	Convertible Roof: Check for function and damage, clean and lubricate (if applicable)
☐	CV Joints: Check for leaks and damage
☐	Door Checks: Lubricate
☐	Engine: Change oil and replace oil filter
☐	Engine and Engine Compartment Components: Check (from above) for leaks and damage
☐	Engine and Engine Compartment Components: Check (from below) for leaks and damage, check transmission, final drive, and drive shaft boots
☐	Exhaust System: Check for leaks, damage, and secure fittings
☐	Fuel Filter: Replace (TDI engines only)

Labor Item	
☐	BorgWarner Clutch: Change oil (if applicable)
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Headlamps: Check adjustment
☐	Interior and Glove Box Lamps, Cigarette Lighter/Power Outlets, Horn, And All Warning Lamps: Check
☐	Power Steering: Check oil level
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Retractable Hard Top: Check for function and damage (if applicable)
☐	Ribbed V-belt: Check condition
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Spark Plugs: Replace (1.9L, 2.5L and 3.2L only)
☐	Sunroof: Check, clean, and lubricate (if applicable)
☐	Sunroof Drains - Check for blockage, clean if necessary (if applicable)
☐	Tie Rod Ends: Check for excessive play, check boots
☐	Tires: Check tread depth, condition, wear pattern, and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Transmission: Automatic: Change Fluid (2.5L Jetta models, NB, NBC, Rabbit and Golf)
☐	Transmission DSG: Change fluid and filter
☐	Underbody Sealant: Inspect for damage
☐	Windshield Washer system: Check function and fluid level (add if necessary), and inspect for damage
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality
☐	Test drive and final check

1.1.6 Service at 50,000 miles or 1 Year after Last Service

Labor Item	
☐	Brake Pads: Check thickness
☐	Engine: Change oil and replace oil filter
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Tires: Rotate front to rear

Labor Item	
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality

1.1.7 Service at 60,000 miles or 1 Year after Last Service

Labor Item	
☐	Air filter element: Replace and clean housing (if applicable)
☐	Battery: Check
☐	Brake pads: Inspect brake system for leaks and damage, check thickness of brake pads, and check brake fluid level
☐	Engine: Change oil and replace oil filter
☐	Fuel Filter: Replace (2.0L TDI only)
☐	Fuel Filter: Drain water (3.0 L TDI only)
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Spark Plugs: Replace (1.8L, 2.0L, 3.6L and 4.2L only)
☐	Tires: Check tread depth, condition, wear pattern, and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality

1.1.8 Service at 70,000 miles or 1 Year after Last Service

Labor Item	
☐	Brake Pads: Check thickness
☐	Engine: Change oil and replace oil filter
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Tires: Rotate front to rear
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality

1.1.9 Service at 80,000 miles or 1 Year after Last Service

Labor Item	
☐	Battery: Check
☐	Body: Visual inspection for corrosion
☐	Brakes: Inspect brake system for leaks and damage, check thickness of brake pads, and check brake fluid level
☐	Convertible Roof: Check for function and damage, clean and lubricate (if applicable)
☐	Coolant Level And Frost Protection: Check
☐	CV Joints: Check for leaks and damage
☐	Door Checks: Lubricate
☐	Engine: Change oil and replace oil filter
☐	Engine and Engine Compartment Components: Check (from above) for leaks and damage
☐	Engine and Engine Compartment Components: Check (from below) for leaks and damage, check transmission, final drive, and drive shaft boots
☐	Exhaust System: Check for leaks, damage, and secure fittings
☐	Fuel Filter: Replace (TDI engines only)
☐	BorgWarner Clutch: Change oil (if applicable)
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Headlamps: Check adjustment
☐	Interior and Glove Box Lamps, Cigarette Lighter/Power Outlets, Horn, and All Warning Lamps: Check
☐	Power Steering: Check oil level
☐	Retractable Hard Top: Check for function and damage (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Ribbed V-belt: Check condition
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Spark Plugs: Replace (1.9L, 2.5L and 3.2L only)
☐	Sunroof: Check, clean, and lubricate (if applicable)
☐	Sunroof Drains - Check for blockage, clean if necessary (if applicable)
☐	Tie Rod Ends: Check for excessive play, check boots
☐	Tires: Check tread depth, condition, wear pattern, and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Transmission: Automatic: Change Fluid (2.5L Jetta models, NB, NBC, Rabbit and Golf)
☐	Transmission DSG: Change fluid and filter
☐	Underbody Sealant: Inspect for damage
☐	Windshield: Check cleaning nozzle functionality

Labor Item	
☐	Windshield and Headlamp Washer Systems: Check function and fluid level (add if necessary), and inspect for damage
☐	Wiper Blades: Check functionality
☐	Test drive and final check

1.1.10 Service at 90,000 miles or 1 Year after Last Service

Labor Item	
☐	Brake Pads: Check thickness
☐	Engine: Change oil and replace oil filter
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Tires: Rotate front to rear
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality

1.1.11 Service at 100,000 miles or 1 Year after Last Service

Labor Item	
☐	Battery: Check
☐	Brakes: Inspect brake system for leaks and damage, check thickness of brake pads, and check brake fluid level
☐	Engine: Change oil and replace oil filter
☐	Fuel Filter: Replace (2.0L TDI only)
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Tires: Check tread depth, condition, wear pattern, and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality

1.1.12 Service at 110,000 miles or 1 Year after Last Service

Labor Item	
☐	Brake Pads: Check thickness
☐	Engine: Change oil and replace oil filter
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Timing Belt: Replace (if applicable)
☐	Tires: Rotate front to rear
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper Blades: Check functionality

1.1.13 Service at 120,000 miles or 1 Year after Last Service

Labor Item	
☐	Battery: Check
☐	Body: Visual inspection for corrosion
☐	Brakes: Inspect brake system for leaks and damage, check thickness of brake pads, and check brake fluid level
☐	Convertible Roof: Check for function and damage, clean and lubricate (if applicable)
☐	Coolant Level And Frost Protection: Check
☐	CV Joints: Check for leaks and damage
☐	Diesel Particle Filter: Check
☐	Door Checks: Lubricate
☐	Engine: Change oil and replace oil filter
☐	Engine and Engine Compartment Components: Check (from above) for leaks and damage
☐	Engine and Engine Compartment Components: Check (from below) for leaks and damage, check transmission, final drive, and drive shaft boots
☐	Exhaust System: Check for leaks, damage, and secure fittings
☐	Fuel Filter: Replace (TDI engines only)
☐	BorgWarner Clutch: Change oil (if applicable)
☐	Headlamps: Check cleaning nozzle functionality (if applicable)
☐	Headlamps: Check adjustment
☐	Interior and Glove Box Lamps, Cigarette Lighter/Power Outlets, Horn, and All Warning Lamps: Check
☐	Power Steering: Check oil level
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Retractable Hard Top: Check for function and damage (if applicable)

Labor Item	
☐	Ribbed V-belt: Check condition
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service label and apply to the driver's side door pillar
☐	Spark Plugs: Replace (all gasoline engines)
☐	Sunroof: Check, clean, and lubricate (if applicable)
☐	Sunroof Drains - Check for blockage, clean if necessary (if applicable)
☐	Tie Rod Ends: Check for excessive play, check boots
☐	Timing Belt: Replace (2.0L TDI only)
☐	Tires: Check tread depth, condition, wear pattern, and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Transmission: Automatic: Change Fluid (2.5L Jetta models, NB, NBC, Rabbit and Golf)
☐	Transmission DSG: Change fluid and filter
☐	Underbody Sealant: Inspect for damage
☐	Windshield: Check cleaning nozzle functionality
☐	Windshield and headlamp washer systems: Check function and fluid level (add if necessary), and inspect for damage
☐	Wiper Blades: Check functionality
☐	Test drive and final check

1.1.14 Service at 130,000 miles or 1 Year after Last Service

Labor Item	
☐	Brake pads: Check thickness
☐	Diesel particle filter: Check ash content within the filter. Replace the filter if ash content is greater than .46 liters (3.0 L TDI engine only)
☐	Engine: Change oil and replace oil filter
☐	Headlight: Check cleaning nozzle functionality (if applicable)
☐	Rear window: Check cleaning nozzle functionality (if applicable)
☐	Service interval display: Reset
☐	Service sticker: Enter the date of the next service on the service sticker and apply to the driver's side door pillar
☐	Tires: Rotate front to rear
☐	Windshield: Check cleaning nozzle functionality
☐	Wiper blades: Check functionality

1.1.15 Time-Dependent Maintenance Items

Labor Item		
☐	Every 1 year	Perform visual check of airbag system
☐	Every 2 years	Dust and pollen filter: Replace (if applicable)
		Check latch for convertible roof (if applicable)
		Tire filler bottle in the tire mobility set: Check (observe expiration date)
		Brake and Clutch System, Changing Brake Fluid (New Beetle)
☐	Every 3 years, then every 2 years regardless of miles driven	Brake and Clutch System, Changing Brake Fluid (Touareg, Eos, Passat, Jetta models, GTI, Rabbit, Tiguan, Passat CC)
☐	Every 4 years regardless of miles driven	Tire Filler Bottle In The Tire Mobility Set: Replace (Observe Expiration Date)
☐	Every 6 years regardless of miles driven	Spark Plugs: Replace
		Air Filter Element: Replace and clean housing
		Tire Pressure Sensors: Replace (where applicable)

1.2 Canada Maintenance Schedule (Except Routan)

✓ all completed items

1.2.1 Service at 15,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Brake Pads: Check thickness and brake disc condition (front and rear)
☐	Engine: Change oil and replace oil filter
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.2 Service at 30,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Battery: Check

Labor Item	
☐	Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition and check brake fluid level
☐	Engine: Change oil and replace oil filter
☐	Fuel Filter: Replace (2.0L TDI only)
☐	Fuel Filter: Drain water (3.0 L TDI only)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.3 Service at 45,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Brake Pads: Check thickness and brake disc condition (front and rear)
☐	Engine: Change oil and replace oil filter
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.4 Service at 60,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Battery: Check
☐	Body: Visual inspection for corrosion
☐	Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition and check brake fluid level
☐	Coolant level and frost protection: Check
☐	Convertible Roof, CSC Roof and Retractable Hard Top: Check for function and damage, clean and lubricate seals (if applicable)

Labor Item	
☐	CV joints: Check for leaks and damage
☐	Door checks and mounting pins: Lubricate
☐	Dust and pollen filter: Replace (if applicable)
☐	Engine: Change oil and replace oil filter
☐	Engine and engine compartment components: Check (from above) for leaks and damage
☐	Engine and engine compartment components: Check (from below) for leaks and damage, check transmission, final drive and drive shaft boots
☐	Exhaust system: Check for leaks, damage and secure fittings
☐	Fuel Filter: Replace (2.0L TDI and 3.0 L TDI only)
☐	BorgWarner clutch: Change oil (if applicable)
☐	Headlamps: Check adjustment
☐	Interior lighting and glove box lights, cigarette lighter/power outlets, horn, and all warning lamps: Check
☐	Lighting: Check front and rear lights, luggage compartment lighting, turn signals, hazard warning lights, daytime running lights, curve lighting, and automatic headlights: Check
☐	Power steering: Check oil level (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Ribbed V-belt: Check condition
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Spark Plugs: Replace (2.5, 3.2, and 3.6L only)
☐	Spark Plugs: Replace (All 2.0L only)
☐	Sunroof and Panoramic sunroof: Check, clean, and lubricate (if applicable)
☐	Sunroof Drains - Check for blockage, clean if necessary (if applicable)
☐	Test Drive: Check braking, kick-down, steering, electrical, heating and ventilation systems, air conditioning, and handling
☐	Tie Rod Ends: Check for excessive play, check boots
☐	Tires: Check tread depth, condition, wear pattern, and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Transmission: Automatic: Change Fluid (2.5L Jetta models, NB, NBC, Rabbit and Golf)
☐	Transmission: DSG: Change fluid and filter
☐	Underbody Sealant: Inspect for damage
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.5 Service at 75,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Brake Pads: Check thickness and brake disc condition (front and rear)
☐	Engine: Change oil and replace oil filter
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.6 Service at 90,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Air Filter Element and Snow Filter: Replace and clean housing (if applicable)
☐	Battery: Check
☐	Engine: Change oil and replace oil filter
☐	Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition and check brake fluid level
☐	Fuel Filter: Replace (2.0L TDI only)
☐	Fuel Filter: Drain water (3.0 L TDI only)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Spark Plugs: Replace (2.0L gasoline engine only)
☐	Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.7 Service at 105,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Brake Pads: Check thickness and brake disc condition (front and rear)

Labor Item	
☐	Engine: Change oil and replace oil filter
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.8 Service at 120,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Battery: Check
☐	Body: Visual inspection for corrosion
☐	Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition and check brake fluid level
☐	Convertible Roof, CSC Roof and Retractable Hard Top: Check for function and damage, clean and lubricate seals (if applicable)
☐	Coolant level and frost protection: Check
☐	CV joints: Check for leaks and damage
☐	Door checks and mounting pins: Lubricate
☐	Dust and pollen filter: Replace (if applicable)
☐	Engine: Change oil and replace oil filter
☐	Engine and engine compartment components: Check (from above) for leaks and damage
☐	Engine and engine compartment components: Check (from below) for leaks and damage, check transmission, final drive and drive shaft boots
☐	Exhaust system: Check for leaks, damage and secure fittings
☐	Fuel Filter: Replace (2.0L TDI and 3.0 L TDI only)
☐	BorgWarner clutch: Change oil (if applicable)
☐	Headlamps: Check adjustment
☐	Interior lighting and glove box lights, cigarette lighter/power outlets, horn, and all warning lamps: Check
☐	Lighting: Check front and rear lights, luggage compartment lighting, turn signals, hazard warning lights, daytime running lights, curve lighting, and automatic headlights: Check
☐	Power steering: Check oil level (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Ribbed V-belt: Check condition
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset

Labor Item	
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Spark Plugs: Replace (2.5, 3.2, and 3.6L only)
☐	Spark Plugs: Replace (All 2.0L only)
☐	Sunroof and Panoramic sunroof: Check, clean, and lubricate (if applicable)
☐	Sunroof Drains - Check for blockage, clean if necessary (if applicable)
☐	Test Drive: Check braking, kick-down, steering, electrical, heating and ventilation systems, air conditioning, and handling
☐	Tie Rod Ends: Check for excessive play, check boots
☐	Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Transmission: Automatic: Change Fluid (2.5L Jetta models, NB, NBC, Rabbit and Golf)
☐	Transmission: DSG: Change fluid and filter
☐	Underbody Sealant: Inspect for damage
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.9 Service at 135,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Brake Pads: Check thickness and brake disc condition (front and rear)
☐	Engine: Change oil and replace oil filter
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.10 Service at 150,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Battery: Check
☐	Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition and check brake fluid level
☐	Engine: Change oil and replace oil filter
☐	Fuel Filter: Replace (2.0L TDI only)

Labor Item	
☐	Fuel Filter: Drain water (3.0 L TDI only)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.11 Service at 165,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Brake Pads: Check thickness and brake disc condition (front and rear)
☐	Engine: Change oil and replace oil filter
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Timing Belt: Replace (if applicable except 2.0L TDI)
☐	Tires: Rotate front to rear
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.12 Service at 180,000 Kilometers or 1 Year after Last Service

Labor Item	
☐	AdBlue® Fluid: Check and add if necessary (3.0 L TDI only)
☐	Battery: Check
☐	Body: Visual inspection for corrosion
☐	Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition and check brake fluid level
☐	Convertible Roof, CSC Roof and Retractable Hard Top: Check for function and damage, clean and lubricate seals (if applicable)
☐	Coolant level and frost protection: Check
☐	CV joints: Check for leaks and damage

Labor Item	
☐	Diesel particulate filter: (ONLY after 180,000 km) Check ash loading according to manufacturer work procedure; Replace if necessary. (2.0L and 3.0 L TDI engine only) **NOTE: If DPF replacement is not necessary, perform check every 30,000 km thereafter until replacement becomes necessary. Subsequent DPF replacement interval is a minimum of 180,000 km thereafter.**
☐	Door checks and mounting pins: Lubricate
☐	Dust and pollen filter: Replace (if applicable)
☐	Engine and engine compartment components: Check (from above) for leaks and damage
☐	Engine: Change oil and replace oil filter
☐	Engine and engine compartment components: Check (from below) for leaks and damage, check transmission, final drive and drive shaft boots
☐	Exhaust system: Check for leaks, damage and secure fittings
☐	Fuel Filter: Replace (2.0L and 3.0 L TDI only)
☐	BorgWarner clutch: Change oil (if applicable)
☐	Headlamps: Check adjustment
☐	Interior lighting and glove box lights, cigarette lighter/power outlets, horn, and all warning lamps: Check
☐	Lighting: Check front and rear lights, luggage compartment lighting, turn signals, hazard warning lights, daytime running lights, curve lighting, and automatic headlights: Check
☐	Power steering: Check oil level (if applicable)
☐	Rear Window: Check cleaning nozzle functionality (if applicable)
☐	Ribbed V-belt: Check condition
☐	Second Battery: Check (if applicable)
☐	Service Interval Display: Reset
☐	Service Label: Enter the date of the next service on the service sticker and apply to the driver side door pillar
☐	Spark Plugs: Replace (2.5, 3.2, and 3.6L only)
☐	Spark Plugs: Replace (All 2.0L only)
☐	Sunroof and Panoramic sunroof: Check, clean, and lubricate (if applicable)
☐	Sunroof Drains - Check for blockage, clean if necessary (if applicable)
☐	Test Drive: Check braking, kick-down, steering, electrical, heating and ventilation systems, air conditioning, and handling
☐	Tie Rod Ends: Check for excessive play and check boots
☐	Timing Belt: Replace (2.0L TDI only)
☐	Tires: Check tread depth, condition, wear pattern, and pressure of all tires (including spare)
☐	Tires: Rotate front to rear
☐	Transmission: Automatic: Change Fluid (2.5L Jetta models, NB, NBC, Rabbit and Golf)
☐	Transmission: DSG: Change fluid and filter

Labor Item	
☐	Underbody Sealant: Inspect for damage
☐	Windshield Washer, Headlight Cleaning System, and Wiper Blades: Check for damage and function, Check fluid level and add if necessary

1.2.13 Time-Dependent Maintenance Items

Labor Item		
☐	Every 1 year	Perform visual check of airbag system
☐	Every 2 years	Dust and pollen filter: Replace (if applicable)
		Brake and Clutch System, Changing Brake Fluid (New Beetle)
		Check latch for convertible roof (if applicable)
		Tire filler bottle in the tire mobility set: Check (observe expiration date)
☐	Every 3 years, then every 2 years regardless of Kilometers driven	Brake and Clutch System, Changing Brake Fluid (Touareg, Eos, Passat, Jetta models, GTI, Golf, Tiguan, Passat CC)
☐	Every 4 years regardless of Kilometers driven	Tire filler bottle in the tire mobility set: Replace (observe expiration date)
☐	Every 6 years regardless of Kilometers driven	Spark Plugs: Replace
		Air filter element: Replace and clean housing
		Tire pressure sensors: Replace (where applicable)
☐	Brake Fluid Replacement	The brake fluid must be replaced every 2 years regardless of kilometers driven, and every 2 years thereafter regardless of kilometers driven (New Beetle)
		The brake fluid must be replaced every 3 years regardless of kilometers driven, and every 2 years thereafter regardless of kilometers driven (Touareg, Eos, Passat, Jetta models, GTI, Golf, Tiguan, Passat CC)

1.3 Maintenance Schedule (Routan Only)

✓ all completed items

Every 6,000 miles or 1 Year after Last Service (10,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on

Every 12,000 miles or 1 Year after Last Service (20,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Inspect the engine air filter if using your vehicle in dusty or off-road conditions: Replace if necessary
☐	Replace the air conditioning filter (if equipped)
☐	Inspect the brake linings: Replace if necessary
☐	Inspect the exhaust system
☐	Inspect the front suspension, tie rod ends, and boot seals for cracks or leaks and all parts for damage, wear, improper looseness or end play: replace if necessary

Every 18,000 miles or 1 Year after Last Service (30,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Inspect the CV Joints
☐	Inspect the exhaust system (Canada only)

Every 24,000 miles or 1 Year after Last Service (40,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Inspect the engine air filter if using your vehicle in dusty or off-road conditions: Replace if necessary (USA only)
☐	Replace the air conditioning filter (if equipped)
☐	Replace the engine air cleaner filter (Canada only)
☐	Inspect the brake linings: Replace if necessary
☐	Inspect the exhaust system (USA only)
☐	Inspect the front suspension, tie rod ends, and boot seals for cracks or leaks and all parts for damage, wear, improper looseness or end play: replace if necessary

Every 42,000 miles or 1 Year after Last Service (50,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Inspect the engine air filter if using your vehicle in dusty or off-road conditions: Replace if necessary (Canada only)
☐	Replace the air conditioning filter (if equipped)
☐	Replace the engine air cleaner filter (USA only)
☐	Inspect the brake linings: Replace if necessary
☐	Inspect the CV joints (Canada only)

Every 42,000 miles or 1 Year after Last Service (50,000 km)	
☐	Inspect the exhaust system (Canada only)
☐	Inspect the front suspension, tie rod ends, and boot seals for cracks or leaks and all parts for damage, wear, improper looseness or end play: replace if necessary
☐	Change the automatic transaxle fluid and filter if using your vehicle for any of the following: Police, taxi, fleet or frequent trailer towing (USA only)

Every 48,000 miles or 1 Year after Last Service (60,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Inspect the CV joints (USA only)
☐	Inspect the exhaust system (USA only)

Every 54,000 miles or 1 Year after Last Service (70,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Replace the air conditioning filter (if equipped)
☐	Replace the engine air cleaner filter (Canada only)
☐	Inspect the brake linings: Replace if necessary
☐	Inspect the front suspension, tie rod ends, and boot seals for cracks or leaks and all parts for damage, wear, improper looseness or end play: replace if necessary
☐	Change the automatic transaxle fluid and filter if using your vehicle for any of the following: Police, taxi, fleet or frequent trailer towing (Canada only)

Every 60,000 miles or 1 Year after Last Service (80,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Replace the engine air cleaner filter (USA only)
☐	Replace the air conditioning filter (if equipped) (USA only)
☐	Inspect the brake linings: Replace if necessary (USA only)
☐	Inspect the CV joints
☐	Inspect the exhaust system
☐	Inspect the front suspension, tie rod ends, and boot seals for cracks or leaks and all parts for damage, wear, improper looseness or end play: replace if necessary (USA only)
☐	Inspect and replace the PCV Valve if necessary (USA only)
☐	Replace the spark plugs (USA only)

Every 66,000 miles or 1 Year after Last Service (90,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Flush and replace the engine coolant (specified mileage or every 5 years) (USA only)
☐	Inspect the engine air filter if using your vehicle in dusty or off-road conditions: Replace if necessary (Canada only)
☐	Replace the air conditioning filter (if equipped) (Canada only)
☐	Inspect the brake linings: Replace if necessary (Canada only)
☐	Inspect the front suspension, tie rod ends, and boot seals for cracks or leaks and all parts for damage, wear, improper looseness or end play: replace if necessary (Canada only)

Every 72,000 miles or 1 Year after Last Service (100,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Inspect the engine air filter if using your vehicle in dusty or off-road conditions: Replace if necessary (USA only)
☐	Replace the air conditioning filter (if equipped)
☐	Replace the engine air cleaner filter (Canada only)
☐	Inspect the brake linings: Replace if necessary
☐	Inspect the CV joints (Canada only)
☐	Inspect the exhaust system (Canada only)
☐	Inspect the front suspension, tie rod ends, and boot seals for cracks or leaks and all parts for damage, wear, improper looseness or end play: replace if necessary (Canada only)
☐	Replace the spark plugs (Canada only)
☐	Inspect and replace the PCV Valve if necessary (Canada only)
☐	Inspect the front suspension, tie rod ends, and boot seals for cracks or leaks and all parts for damage, wear, improper looseness or end play: replace if necessary (USA only)

Every 78,000 miles or 1 Year after Last Service (110,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Flush and replace the engine coolant (specified mileage or every 5 years) (Canada only)

Every 84,000 miles or 1 Year after Last Service (120,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Inspect the CV joints

Every 84,000 miles or 1 Year after Last Service (120,000 km)	
☐	Inspect the exhaust system
☐	Change the automatic transaxle fluid and filter
☐	Replace accessory drive belt (s)

Every 90,000 miles or 1 Year after Last Service (130,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Replace engine air cleaner filter
☐	Inspect and replace PCV valve if necessary

Every 96,000 miles or 1 Year after Last Service (140,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Inspect engine air cleaner filter
☐	Replace air conditioning filter (4.0 L only)
☐	Inspect brake linings
☐	Inspect CV Joints
☐	Inspect exhaust system
☐	Inspect front suspension, tie rod ends and boot seals

Every 102,000 miles or 1 Year after Last Service (150,000 km)	
☐	Change oil and filter
☐	Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on
☐	Flush and replace engine coolant
☐	Replace ignition cables (3.8L engine)
☐	Replace spark plugs (3.8L and 4.0 L Engine)
☐	Replace timing belt (4.0 L Engine)

© 06.2024 Volkswagen Group of America, Inc.
All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen Group of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.